

APPLICATION INSTRUCTIONS

POLYX[®]-OIL ORIGINAL CLEAR - 3054, 3055

MECHANICALLY WITH A BRUSH OR ROLLER AND FLOOR BUFFER

First Coat: Apply one thin coat with an Osmo Floor Roller, Osmo Floor Brush.

1. Stir the Polyx[®]-Oil well prior to use.
2. Brush or roll the product thinly and evenly onto the floor.
3. Do not remove excess product, this will absorb into the floor over drying period
4. Allow approx. 8-10 hours for product to dry before proceeding to second coat

Second Coat: Apply a second thin coat and remove all excess with a buffing machine.

1. Brush or roll the second coat thinly and evenly onto the floor.
2. Allow approx. 5-10 minutes for product to penetrate surface
3. Prior to buffing, remove excess product from room corners with a white scotchbrite pad
4. Disperse and polish the floor, removing excess using a floor buffer and white pads
5. There is too much material on the surface when you can see rings. If so, turn the pad over.
6. Allow 8-10 hours drying time. Allow for good ventilation whilst drying

Third Coat: Usually a third coat is not required, however highly absorbent or dry timbers may appear to require a third coat.

Please consult OSMO technical support at 1-844-OSMOCAN prior to carrying out a third coat.

Tinting: Osmo Wood Wax Finish can also be used to lightly tint Polyx[®]-Oil 3054 up to a ratio of 10:1. Do not exceed a ratio of 10 parts Polyx[®]-Oil 3054 to 1 part Wood Wax Finish.

Ex. For Natural (No colour change from Raw Wood) tint Polyx-Oil with Wood Wax Finish 3111 White at 3% for the base-coat, followed by clear (untinted) Polyx-Oil as a top-coat.

Cure Period: Osmo Hardwax-Oil(s) like all floor finishes have a cure period. We recommend allowing 2 weeks for the product to fully cure and harden, prior to damp-mopping or placing rugs/mats.

APPLICATION INSTRUCTIONS

CONTINUED - POLYX[®]-OIL ORIGINAL CLEAR - 3054, 3055

BY HAND WITH A CLOTH/RAG

Apply three thin coats with a lint-free cloth.

1. Stir the Polyx[®]-Oil well and prior to use
2. Work product into wood using cloth in a circular or figure 8 pattern
3. Allow roughly 15-minutes for oils to penetrate
4. Working with the grain, remove all excess product from surface
5. Allow 8-10 hours drying time prior to recoating
6. Apply second and third coats following previous steps



WARNING: Cloths saturated with product are a spontaneous combustion hazard and should be left out unfolded until dried, prior to disposal or preferably stored in a proper fireproof container

BY HAND WITH SCOTCHBRITE PADS

For small areas and furniture, apply two thin coats with non-abrasive, white scotchbrite pads.

1. Stir the Polyx[®]-Oil well and pour a small amount into a disposable container
2. With a white scotchbrite pad work the product into the wood evenly in figure 8 or circular motions
3. Be sure to thinly and evenly coat the surface and leave on the surface for approx. 5 minutes
4. With a clean white scotchbrite pad, polish the surface ensuring no rings or wipe marks
5. Ensure all excess product is removed from surface.
6. Approx. 8-10 hours drying time. Allow for good ventilation whilst drying
7. Apply second coat following previous steps